

THE PRESIDENT

AXXOSHOTELS.com

For any help, please, call reception
+ 420 234 614 100


Coffee preparation



Fill the water tank



Switch the machine on



Flashing light : heating up
Steady light: ready



Lift the lever completely
and insert a nespresso capsule



Close the lever and place
a cup under the coffee
outlet



Espresso button (small cup)
Lungo button (large cup)



Enjoy

THE PRESIDENT

AXXOSHOTELS.com

For any help, please, call reception
+ 420 234 614 100

Tea preparation



1

Fill the water tank



2

Switch the machine on





3

Flashing light : heating up
Steady light: ready




4

Place the cup and press once the small coffee button
to drain the water.



5

Remove and empty the
cup.



6

Espresso button (small cup) - Lungo button (large cup)



Enjoy